



03-04-185 Back Seal Bang



086-2543-19 Link, Seal Checker Base, Right Side



102-8368-08 Bracket



103-8870-18 Nozzle, Air



105-6719-15 Heater Block



107-0548-09 Shaft, Timing Link



108-2578-05 Stopper, Stripper



108-2705-01 Damper



109-3996-00 Bumper



109-3997-03Plate, Shutter, Rear



109-6427-26 Link, Shutter



109-6428-20 Link, Shutter



110-4753-09 Stripper, Sheet



111-1630-01 Lever



111-4094-23
Funnel, Discharge, Bottom 4.5"
Diameter, top 7.5" Diameter,
with 1 inch extension



111-7185-01 Shutter Plate, Front



111-8676-07Cam Follower




116-1468-00 Shaft, Drive



Funnel, Discharge, Bottom 7"
Diameter, top 8" Diameter, with
1 inch extension



20516919 Bearing, Cam Follower



24-1705-03 Flexor



24-1761-02 Flexor



50-6620-25 Bracket, Seal Jaw Left



50-6620-34 Bracket, Seal Jaw Left



Bracket, Seal Jaw Right





50-6621-38 Bracket, Seal Jaw Right



50-6632-01 Case



50-6635-02 Case



50-6645-00 Knife Blade



50-6874-06 Heater, Distance



50-6898-14Band, Back Seal



51-4615-17Pulley, Drive



51-4840-19 Shaft



51-4866-06Knife



51-4878-10 Hanger, Spring Holder



51-4886-01-ADeflator Spring Assembly Includes Qty. 2 51-4878-10AH
Hangers and Qty. 1 51-488601AH Spring



51-4886-01 Spring, Deflator



51-4893-16 Link, Double



51-4896-17 Pull Belt



52-3335-18Cartridge Heater



52-3337-15 Heater Probe




Deflator Spring Assembly -Includes Qty. 2 51-4878-10AH Hangers and Qty. 1 52-6087-06AH Spring



-6087-06 Spring



54-3731-14Bushing



54-9629-00 Plate



54-9630-04 Plate



55-3201-05Bushing, Guide Rod



58-6178-05Bushing



58-8795-10Bracket



58-8830-17 Shaft, Drive





58-8844-00Bushing, Bronze



61-8568-00 Block, Eccentric



61-8820-18Pulley, 64 Tooth



61-8989-04 Shaft, Stripper Plate



62-1015-09Pull Belt



62-1085-19Gear Rack, Metric, 270mm
Long



62-1086-Gear Rack, 350mm Long



62-1285-08 Slider, Rack



62-1286-01 Slider



62-6491-07 Link, Shaft, Pull Belt Ass'y



64-5457-01 Heater Block



64-5472-07 Gear



64-8253-09Gear Rack, Metric, 280mm
Long



64-8254-11Gear Rack, Metric, 240mm
Long



64-9012-01 Support, Jaw



4-9044-01 Base Link



64-9211-06 Gear, Double



5-2432-04 Spring



Shutter, Front



67-0563-06Shutter, Rear



67-0564-19 Shaft



67-0566-07Block "B" Stopper, Damper



67-0567-01Block "B" Stopper, Damper



67-0568-04. Block, Shutter



67-5144-07Cartridge Heater, 220V x 700W





67-5242-09Cartridge Heater, 1000W x 220V



67-5376-04Shutter, Damper



67-5377-08Spring, Extension



67-5380-19Bolt, Shutter Stopper




68-3735-08 Filter, Air,




68-3806-09Stopper, Damper



68-3819-16Holder, Shutter



68-3846-08Damper



68-7414-07Filter, Air, Vacuum Pump



69-2975-27Chute, Funnel Transition,



69-9025-15 Stripper Block, Rear



69-9028-07Bolt



70-0938-16Chute, Funnel Transition,
Small



70-4797-03Bracket, Spring Holder



71-1240-02Block, Stopper



71-1241-06Block, Stopper



71-1288-10 Stripper Block, Rear



1-1304-0 */* Shaft, Stripper



72-1762-16 Pin, Step



72-1763-10 Block, B Film End



72-3802-00Holder, Shutter



74-7620-08 Shutter



74-7866-16 Gear



74-7867-10 Gear



76-1189-01Coupling, 3-1/4"

Infinity Products, Inc. Aftermarket Parts for: Ishida Apex/Atlas



76-5063-01Gear, Double



76-5479-06 Gear Rack



76-5480-01 Gear Rack



77-2365-01 Heater Block



78-5117-21 Lever



78-5122-20 Lever



78-5126-15 Shaft



85-2793-07Conduit, Flexible



91-4653-06 Gear Rack



91-4654-00 Gear Rack



91-8458-01 Ring, Quad



92-2364-00 Lever, Cutter



92-2365-03 Lever, Cutter



93-6717-02Plate



94-9029-01 Bracket, Air Knife Cylinder



94-9030-06Bracket



Thermocouple 1" x 1/8"



4-9031-28 Sensor



94-9327-01 Stopper



94-9479-04Gear, Spur



95-0163-02-A
Deflator Spring Assembly Includes Qty. 2 96-9077-05AH
Hangers and Qty. 1 95-016302AH Spring



95-0163-02Spring, Deflator



95-0499-03 Gear, Spur



Deflator Spring Assembly -Includes Qty. 2 - 96-9077-05 Hangers and Qty. 1 - 52-6087-06 Spring



96-9077-05 Hanger, Deflator Spring





96-9120-02 Shaft, Support



97-9410-00 Lever, Cutter



97-9411-03 Lever, Cutter



97-9411-21 Lever



99-2362-12 Spring, Assembly, Steel Tension Coil




CO-1721 Scalloped Blade



ERCT-1046 Pull Belt



X56-6033-04Ball Bearing



X94-9031-19 Heat Sensor



XCO-1721 Scalloped Blade